

SPOOL RACK

ASSEMBLY INSTRUCTIONS



PARTS

- 2 – bases
- 2 – uprights
- 1 – bottom brace
- 1 – center pivot
- 1 – top brace

HARDWARE


- 2 – 3 1/2" truss-head machine screws
- 4 – 1 3/4" flat head machine screws
- 2 – 2 1/2" truss head machine screws
- 8 – barrel nuts
- 10 – metal rods
- 10 – 1" Phillips head screws

ASSEMBLY

1. Assemble the bases to the uprights using (2) 3 1/2" truss-head machine screws and (2) barrel nuts as shown in the diagram.
2. Assemble the bottom brace to the bases using (2) 2 1/2" long machine screws and (2) barrel nuts. Make sure the notch in the center of the brace faces up.
3. Install the ten metal rods into the holes in the center pivot so that the bars extend evenly on each side. You can rub the rods with bar soap to help

them slide in. When all the rods are installed, secure each rod with one of the 1" Phillips screws.

4. Place the center pivot with metal rods in position into the hole and notch in the bottom brace.
5. Assemble the top brace to the uprights with the 1 3/4" long machine screws and barrel nuts. Make sure the center pivot hole faces down.
6. To turn the center pivot, simply lift and turn. The center pivot will lock itself in place when in its normal use. ■



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2013 Schacht Spindle Company, Inc.

SPOOL RACK

ASSEMBLY INSTRUCTIONS



PARTS

- 2 – bases
- 2 – uprights
- 1 – bottom brace
- 1 – center pivot
- 1 – top brace

HARDWARE


- 2 – 3 1/2" truss-head machine screws
- 4 – 1 3/4" flat head machine screws
- 2 – 2 1/2" truss head machine screws
- 8 – barrel nuts
- 10 – metal rods
- 10 – 1" Phillips head screws

ASSEMBLY

1. Assemble the bases to the uprights using (2) 3 1/2" truss-head machine screws and (2) barrel nuts as shown in the diagram.
2. Assemble the bottom brace to the bases using (2) 2 1/2" long machine screws and (2) barrel nuts. Make sure the notch in the center of the brace faces up.
3. Install the ten metal rods into the holes in the center pivot so that the bars extend evenly on each side. You can rub the rods with bar soap to help

them slide in. When all the rods are installed, secure each rod with one of the 1" Phillips screws.

4. Place the center pivot with metal rods in position into the hole and notch in the bottom brace.
5. Assemble the top brace to the uprights with the 1 3/4" long machine screws and barrel nuts. Make sure the center pivot hole faces down.
6. To turn the center pivot, simply lift and turn. The center pivot will lock itself in place when in its normal use. ■



Find out more at schachtspindle.com
Schacht Spindle Company 6101 Ben Place Boulder, CO 80301
p. 303.442.3212 f. 303.447.9273
© 2013 Schacht Spindle Company, Inc.